


12' EXCEL STALL VENTED LUMBER KIT



HLKSV12



FOR MORE INFORMATION, QUESTIONS, OR CONCERNS,
PLEASE CONTACT TARTER CUSTOMER SERVICE:
1.800.RED.GATE (1.800.733.4283)

KIT INCLUDES:

- (10) 69-1/2" X 6-3/4" TONGUE AND GROOVE
- (2) 69-1/2" X 6-3/4" GROOVE ONLY
- (2) 69-1/2" X 4-1/4" GROOVE ONLY

TOOLS NEEDED:

- PHILLIPS SCREW DRIVER
- DRILL
- RUBBER Mallet
- TAPE MEASURE
- CIRCULAR SAW

INSTALLATION NOTES:

- It is recommended to have the stall panel in its final location before installing the lumber kit.
- All boards have a beveled edge. Please be aware for appearance consistency.
- A rubber mallet may be used to secure the boards tightly without damaging them.



GROOVE



TONGUE



BEVELED EDGE

INSTALLATION INSTRUCTIONS:

- 1.** Begin installation on either bottom side. Fully install one side before starting opposite side.
- 2.** Install 5 - 69-1/2" x 6-3/4" tongue and groove boards, with tongue face up. The first few boards can be installed by leaning at an angle and sliding in the channel.
- 3.** Install 1 - 69-1/2" x 6-3/4" board, with groove only. Make sure groove is face down. Use notch to install final boards.
- 4.** Install 1 - 69-1/2" x 4-1/4" board, with groove only. Make sure groove is face down. Top board may need to be cut to fit properly. Cut must be made to the flat edge.
- 5.** Secure lumber with 2 - #10 x 1" Phillips screws, using the pre-drilled holes in the channel. It is important to screw the lumber in so the boards do not come out. (Included in stall hardware)
- 6.** Repeat steps 2-5 on opposite side.

