

# 12' EXCEL STALL SIDE LUMBER KIT

////////////////////////////////////

HLKSS12



FOR MORE INFORMATION, QUESTIONS, OR CONCERNS,  
PLEASE CONTACT TARTER CUSTOMER SERVICE:

**1.800.RED.GATE** (1.800.733.4283)

## KIT INCLUDES:

### BOTTOM PORTION

- (10) 69-1/2" X 6-3/4" TONGUE AND GROOVE
- (2) 69-1/2" X 6-3/4" GROOVE ONLY
- (2) 69-1/2" X 4-1/4" GROOVE ONLY

### TOP PORTION

- (6) 69-1/2" X 6-3/4" TONGUE AND GROOVE
- (2) 69-1/2" X 6-3/4" GROOVE ONLY
- (2) 69-1/2" X 5-1/2" GROOVE ONLY

## TOOLS NEEDED:

- PHILLIPS SCREW DRIVER
- DRILL
- RUBBER Mallet
- TAPE MEASURE
- CIRCULAR SAW

## INSTALLATION NOTES:

- It is recommended to have the stall panel in its final location before installing the lumber kit.
- All boards have a beveled edge. Please be aware for appearance consistency.
- A rubber mallet may be used to secure the boards tightly without damaging them.



GROOVE




TONGUE



BEVELED EDGE

## BOTTOM PORTION INSTRUCTIONS:

1. Begin installation on either bottom side. Fully install one side before starting opposite side.
2. Install 5 - 69-1/2" x 6-3/4" tongue and groove boards, with tongue face up. The first few boards can be installed by leaning at an angle and sliding in the channel.
3. Install 1 - 69-1/2" x 6-3/4" board, with groove only. Make sure groove is face down. Use notch to install final boards.
4. Install 1 - 69-1/2" x 4-1/4" board, with groove only. Make sure groove is face down. Top board may need to be cut to fit properly. Cut must be made to the flat edge.
5. Secure lumber with 2 - #10 x 1" Phillips screws, using the pre-drilled holes in the channel. It is important to screw the lumber in so the boards do not come out. (Included in stall hardware)
6. Repeat steps 2-5 on opposite side.



## TOP PORTION INSTRUCTIONS:

1. Begin installation on either top side. Fully install one side before starting opposite side.
2. Install 3 - 69-1/2" x 6-3/4" tongue and groove boards, with tongue face up. The first few boards can be installed by leaning at an angle and sliding in the channel.
3. Install 1 - 69-1/2" x 6-3/4" board, with groove only. Make sure groove is face down. Use notch to install final boards.
4. Install 1 - 69-1/2" x 5-1/2" board, with groove only. Make sure groove is face down. Top board may need to be cut to fit properly. Cut must be made to the flat edge.
5. Secure lumber with 2 - #10 x 1" Phillips screws, using the pre-drilled holes in the channel. It is important to screw the lumber in so the boards do not come out. (Included in stall hardware)
6. Repeat steps 2-5 on opposite side.

